



Time Clock Instructions (Pason)

Getting Started

To ensure that the clock is reset to all its defaults, turn it off using the rocker switch on the right side of the console. Wait a few seconds, and then turn it back on. On the LED screen, you will be asked whether you want to start from where you turned off last. Enter [NO]. You will then be asked to enter the model number [871]. Finally, you will be asked if you want to use penalty time out, Enter [NO].

Setting the Time and Period

[SET] [TIME] [MMSS] [YES] [ENTER PERIOD NUMBER] [YES]

Note: enter the time as two-digit minutes, two-digit seconds and one digit 1/10's. Example: 15000 for 15 minutes.

Starting and Stopping the Clock

Use the hand held rocker switch to start and stop the clock. Be careful, as a small round button on the hand-held will sound the buzzer.

Entering a Goal

[HOME SCORE] OR [GUEST SCORE] [1] [YES]

To correct the score: [SET] [HOME SCORE] OR [GUEST SCORE] THEN [SCORE#]

Entering a Penalty

[SET] [HOME PENALTY] OR [GUEST PENALTY] [MMSS] [YES] [TWO DIGIT PLAYER NUMBER]

Example: if player is #7 then enter 07

Clearing a Penalty

[HOME PENALTY] OR [GUEST PENALTY] THEN [PENALTY CLEAR]

Note: pressing the [HOME PENALTY] OR [GUEST PENALTY] will cycle through the penalties until you reach the right one.

